# MINOLTAFAX5600

## PARTS MANUAL



#### **PREFACE**

- 1. The part numbers listed in Parts Manual are those which were assigned to the parts making up the machine at the time machine was originally introduced onto the market.
- 2. Parts whose INDEX numbers are shown white against a black background in the illustration are those to be used in only certain market areas. These part numbers are given in the lower half part of the list section. Check the SFIX No. listed in SFIX CHART on page II to find which part number is applicable to your own area.
- 3. Parts whose INDEX numbers are shown black against a white background in the illustration are those to be used in all market areas. These parts are listed on the upper half part of the list section.
- 4. If "NS" follows a part number given in the list section, it indicates that we do not keep a stock of the part. The part is not required for ordinary service jobs, either.
- 5. If "RP" is shown in the REC column of the list section, it indicates that the part is functionally important.
- 6. In the exploded views in this Parts Manual the parts (Screws & Washes, etc...) which are indicated with a "four-digit" numbers are listed in numerical order in the section "SCREWS AND WASHERS". Please check these "four-digit" numbers with the part numbers ("ten-digit" numbers) which should be used for ordering the part.
- 7. All part numbers consist of "ten-digit" which should all be quoted when ordering a part. The price of parts can be obtained by referring to the "Parts Price List" which is separately issued.
- 8. All infomation contained in this parts manual is subject to change.

#### PARTS MANUAL


## **CONTENTS**

Ι.		
2.	DRIVE/PAPER TAKE-UP SECTION (A) •••••••••••••••••••••••••••••	• 3
3.	DRIVE/PAPER TAKE-UP SECTION (B)	• 5
4.	TRANSFER UNIT •••••••••••••••••••••••••••••••••	• • 7
5.	FUSING UNIT	• 9
6.	HOUSING/PANEL • • • • • • • • • • • • • • • • • • •	
7.	TRANSMIT SECTION (A) • • • • • • • • • • • • • • • • • • •	
8.	TRANSMIT SECTION (B)••••••••••••••••••••••••••••••••••••	• 15
9.	TRANSMIT SECTION (C)	• 17
10.	SCANNER SECTION.	• 19
11.	FRAMES	• 21
12.	CASSETTE •••••••••••••••••••••••••••••••••	• 23
13.	HANDSET/ACCESSORIES	• 25
14.	SCREWS AND WASHERS ••••••••••••••••••••••••••••••••••••	• 27
15.	NUMERICAL INDEX ************************************	


NOVEMBER 1999

1 HOUSING PARTS MANUAL


 $\bigcirc$ 1




INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4283-1027-01	HOLDER		1					
02	4283-1028-01	HOLDER		2					
03	0997-6102-01	FAN MOTOR	RP	1					
04	0992-2304-13	COVER		1					
05	0992-1006-01	ACTUATOR		1					
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		
			l l						



INDE	PART NO.	PART NAME	REC	QTY	INDE	EX PART NO.	PART NAME	REC	QTY
01	0992-0134-02	PW BOARD (PWB-A	) RP	1	19	0992-4101-12	GUIDE		1
02	4283-1031-01	LABEL		1	20	0992-3002-02	ROLLER	RP	1
03	0992-2001-17	HOLDER		1	21	0992-3501-02	GUIDE		1
04	0956-2027-01	RUBBER STRIP		2	22	9992-3022-02	STOPPER		1
05	0992-3001-24	ROLLER	RP	1	23	0992-0751-01	SEPARATOR	RP	1
06	4275-1022-01	PWB-PU	RP	1	24	0992-3041-01	PRESSURE SPRING		1
07	0992-2414-02	GROUND PLATE		1	25	0992-3006-01	ROLL		2
08	0992-2308-25	COVER		1	26	0992-3502-05	HOLDER		1
09	0992-3008-02	CAM		1	27	0992-6108-01	MOTOR (M1)	RP	1
10	0992-3015-02	HOLDER		1					
11	0992-3019-01	CLUTCH SPRING		1					
12	0992-3010-12	GEAR 40T		1					
13	9335-1410-31	PHOTO INTERRUPTER (PC	) RP	1					
14	0992-3011-02	GEAR 16T		1					
15	0992-6212-13	SOLENOID	RP	1					
16	0992-3014-01	BUSHING		2	2				
17	0992-3021-14	ACTUATOR		1					
18	1200-1236-02	WASHER		1					
INDE	PART NO.	PART NAME	REC	QTY	-		SFIX		




0992-2007-01 0992-2006-03 0992-6225-01 0997-6301-01 0956-2015-01 0992-3025-01 0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-3007-01 0992-3105-01 0992-3105-01 0992-0761-03	PRINT HEAD UNIT TERMINAL TERMINAL PWB-HV (PWB-F) SWITCH RUBBER FOOT PW BOARD-G CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER	RP RP RP	1 1 1 1 4 1 1 1					
0992-2006-03 0992-6225-01 0997-6301-01 0956-2015-01 0957-0101-01 0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-3007-01 0992-3105-01 0992-3105-01 0992-0761-03	TERMINAL PWB-HV (PWB-F) SWITCH RUBBER FOOT PW BOARD-G CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER	RP	1 1 1 4 1					
0992-6225-01 0997-6301-01 0956-2015-01 0957-0101-01 0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-3105-01 0992-3105-01	PWB-HV (PWB-F) SWITCH RUBBER FOOT PW BOARD-G CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER	RP	1 1 4 1					
0997-6301-01 0956-2015-01 0957-0101-01 0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-3005-01 0992-3105-01 0992-0761-03	SWITCH RUBBER FOOT PW BOARD-G CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER	RP	1 4 1					
0956-2015-01 0957-0101-01 0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-3007-01 0992-3105-01 0992-0761-03	RUBBER FOOT PW BOARD-G CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER		4					
0957-0101-01 0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-2024-01 0992-3105-01 0992-0761-03	PW BOARD-G CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER	RP	1					
0992-3025-01 0992-2016-01 0992-2015-01 0992-3007-01 0992-2024-01 0992-3105-01 0992-0761-03	CAM GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER	RP						
0992-2016-01 0992-2015-01 0992-3007-01 0992-2024-01 0992-3105-01 0992-0761-03	GUIDE TORSION SPRING SUPPORT GROUND PLATE SPACER		1 1 1					
0992-2015-01 0992-3007-01 0992-2024-01 0992-3105-01 0992-0761-03	TORSION SPRING SUPPORT GROUND PLATE SPACER		1 1					
0992-3007-01 0992-2024-01 0992-3105-01 0992-0761-03	SUPPORT GROUND PLATE SPACER		1					
0992-2024-01 0992-3105-01 0992-0761-03	GROUND PLATE SPACER							
0992-3105-01 0992-0761-03	SPACER		1					
0992-0761-03			1					
			1					
0004 1011 11	REGULATING PLATE ASSY		1					
9384-1311-11	CABLE TIE 104L		1					
PART NO.	PART NAME	REC	QTY			SFIX		
	PART NO.	PART NO. PART NAME	PART NO.  PART NAME  REC	PART NO. PART NAME REC QTY SFIX	PART NO. PART NAME REC QTY SFIX			



7


INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	0992-3709-01	HOLDER		2					
02	0957-3215-01	BUSHING		2					
03	0992-3707-01	ROLL		2					
04	0957-3208-01	GEAR 15T		1					
05	0992-3720-01	ROLLER		1					
06	0992-0391-08	TRANSFER UNIT	RP	1					
07	0992-4206-01	GEAR 21T		1					
08	0992-4210-01	RING		1					
09	0992-4205-12	BUSHING		1					
10	0992-4203-01	GUIDE PLATE		1					
11	0992-4201-01	ROLLER	RP	1					
12	0992-4213-01	PLATE		1					
13	0992-4204-12	BUSHING		1					
14	0992-0102-24	PW BOARD-R(NO IC)	RP	1					
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		
			l						

**FUSING UNIT** PARTS MANUAL 5




INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	0992-2550-01	ARM		1	19	0992-5541-01	FUSING ROLLER-LWR	RP	1
02	0992-2552-02	HOLDER		1	20	0992-6715-01	THERMISTOR	RP	1
03	0992-2551-01	TORSION SPRING		1	21	0992-5540-01	FUSING ROLLER-UPR	RP	1
04	0992-2508-13	GEAR 25/50T		1	22	0992-6505-01	TUBE LAMP	RP	1
05	0992-0484-01	FUSING UNIT	RP	1	23	0992-4015-03	GUIDE		1
06	0972-5531-01	C-RING		2					
07	0992-5512-01	GEAR 30T		1					
08	0992-5521-01	BUSHING		2					
09	0957-5511-01	BUSHING		2					
10	0992-5517-13	PRESSURE SPRING		2					
11	0992-5533-03	SEPARATOR		3					
12	9335-1410-31	PHOTO INTERRUPTER	RP	1					
13	0992-7841-01	STOPPER		1					
14	0992-5553-01	ACTUATOR		1					
15	0957-5527-02	SEPARATOR ROLL		1					
16	0992-3706-01	GEAR 40T		1					
17	0992-0156-13	HOLDER		1					
18	0992-6713-01	THERMOSTAT	RP	1					
INDEX	DADTNO	DADT NAME	DEO	OTV			OFIV		
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		
			1	I	1				

6 HOUSING/PANEL PARTS MANUAL




01	RP	
03       4283-1056-01       REAR COVER       1       25       4283-1011-01       COVER         04       4283-1006-01       PANEL ASSY       1       26       4283-1058-01       COVER         05       4283-1036-01       LABEL       1       27       4283-1057-01       COVER         06       4283-1053-01       LABEL       1       28       4283-1075-01       TRAY ASSY         07       4283-1054-01       ONE-TOUCH SHEET       1       29       4283-1078-01       TRAY         08       4283-1005-01       COVER ASSY       1       30       4283-1055-01       FRONT COVER         09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1 <td></td> <td></td>		
04       4283-1006-01       PANEL ASSY       1       26       4283-1058-01       COVER         05       4283-1036-01       LABEL       1       27       4283-1057-01       COVER         06       4283-1053-01       LABEL       1       28       4283-1075-01       TRAY ASSY         07       4283-1054-01       ONE-TOUCH SHEET       1       29       4283-1078-01       TRAY         08       4283-1005-01       COVER ASSY       1       30       4283-1055-01       FRONT COVER         09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-107-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1052-01       BRUSH         13       4283-1007-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1007-01       TRAY         16       4275-1149-01       HARNESS       1	RP	
05       4283-1036-01       LABEL       1       27       4283-1057-01       COVER         06       4283-1053-01       LABEL       1       28       4283-1075-01       TRAY ASSY         07       4283-1054-01       ONE-TOUCH SHEET       1       29       4283-1078-01       TRAY         08       4283-1050-01       COVER ASSY       1       30       4283-1055-01       FRONT COVER         09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-1017-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1 <td< td=""><td></td><td></td></td<>		
06       4283-1053-01       LABEL       1       28       4283-1075-01       TRAY ASSY         07       4283-1054-01       ONE-TOUCH SHEET       1       29       4283-1078-01       TRAY         08       4283-1005-01       COVER ASSY       1       30       4283-1055-01       FRONT COVER         09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-1017-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
07       4283-1054-01       ONE-TOUCH SHEET       1       29       4283-1078-01       TRAY         08       4283-1005-01       COVER ASSY       1       30       4283-1055-01       FRONT COVER         09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-1017-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
08       4283-1005-01       COVER ASSY       1       30       4283-1055-01       FRONT COVER         09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-107-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUSH       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
09       4275-1001-01       LCD DISPLAY       RP       1       31       4283-1015-01       SHEET         10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-1017-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
10       4278-1184-01       SPACER       1       32       4283-1016-01       SHEET         11       4275-1144-01       HARNESS       1       33       4283-1017-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
11       4275-1144-01       HARNESS       1       33       4283-1017-01       SHEET         12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
12       4283-1012-01       BUTTON       4       34       4283-1074-01       TRAY ASSY         13       4283-1007-01       BUTTON       1       35       4283-1052-01       BRUSH         14       4279-1001-01       KEY TOP       1       36       4278-1087-01       GUIDE         15       4278-1189-01       SUPPORT       1       37       4283-1077-01       TRAY         16       4275-1149-01       HARNESS       1       38       4278-1086-01       GUIDE		
13     4283-1007-01     BUTTON     1     35     4283-1052-01     BRUSH       14     4279-1001-01     KEY TOP     1     36     4278-1087-01     GUIDE       15     4278-1189-01     SUPPORT     1     37     4283-1077-01     TRAY       16     4275-1149-01     HARNESS     1     38     4278-1086-01     GUIDE		
14     4279-1001-01     KEY TOP     1     36     4278-1087-01     GUIDE       15     4278-1189-01     SUPPORT     1     37     4283-1077-01     TRAY       16     4275-1149-01     HARNESS     1     38     4278-1086-01     GUIDE		
15     4278-1189-01     SUPPORT     1     37     4283-1077-01     TRAY       16     4275-1149-01     HARNESS     1     38     4278-1086-01     GUIDE		
16 4275-1149-01 HARNESS 1 38 4278-1086-01 GUIDE		
17 4278-1058-01 KEY TOP 1 39 4282-1003-01 RACK GEAR		
18 4279-1042-01 KEY TOP 2 40 4283-1050-01 GEAR		
19 4278-1078-01 KEY TOP 1 41 4275-1111-01 PLATE SPRING		
20 4278-1077-01 KEY TOP 1 42 4283-1051-01 COVER		
21 4278-1076-01 KEY TOP 1 43 4256-1081-01 WASHER		
22 4283-1008-01 BUTTON 1		
NIDERY DART NO.		
INDEX PART NO. PART NAME REC QTY SFIX		



INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4275-1050-01	GEAR 20/46T		1	19	4275-1044-01	ROLLER		1
02	4275-1049-01	GEAR 19T		3	20	4275-1051-01	GEAR		1
03	4275-1071-01	GEAR 25T		2					
04	4275-1068-01	SPACER		1					
05	4275-1066-01	BUSHING		2					
06	4283-1059-01	COVER		1					
07	4275-1175-01	BUSHING		8					
08	4275-1046-01	GEAR 32T		1					
09	4275-1183-01	TORQUE LIMITER	RP	1					
10	4275-1043-01	ROLLER		2					
11	4275-1075-01	GEAR		1					
12	4275-1078-01	SHOULDER SCREW		1					
13	4275-1045-01	PRESSURE SPRING		1					
14	4275-1165-01	ROLLER ASSY	RP	1					
15	4283-1018-01	ROLLER ASSY		1					
16	4275-1164-01	GUIDE ASSY		1					
17	4275-1062-01	GROUND PLATE		1					
18	4275-1163-01	GUIDE ASSY		1					
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		

8 TRANSMIT SECTION (B)


PARTS MANUAL



INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4275-1060-01	LEVER		1					
02	4283-1062-01	KNOB		1					
03	4275-1032-01	TENSION SPRING		1					
04	4278-1125-01	GEAR		1					
05	4275-1033-01	BUSHING		1					
06	4278-1124-01	CLUTCH SPRING		1					
07	4283-1033-01	ROLLER ASSY	RP	1					
08	4275-1033-01	BUSHING		1					
09	4283-1061-01	COVER		1					
10	4275-1058-01	GEAR		1					
11	4283-1060-01	GUIDE		1					
12	4275-1004-01	PWB-SWITCH	RP	1					
13	4275-1005-01	PWB-SWITCH	RP	1					
14	4279-1033-01	ROLLER		1					
							2-1/		
INDEX	PART NO.	PART NAME	REC	QIY			SFIX		
				Ī					


9 TRANSMIT SECTION (C)

PARTS MANUAL




INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4253-1027-01	STAMP	RP	1					
02	4275-1061-01	BRACKET		1					
03	4275-1034-01	ROLLER		2					
04	4275-1074-01	GUIDE		2					
05	4275-1070-01	SET PLATE		1					
06	4275-1007-01	MICROSWITCH	RP	1					
07	4275-1072-01	GEAR 21/59T		1					
08	4275-1073-01	GEAR 19/53T		1					
09	4220-1085-01	CORD CLAMP		1					
10	4275-1185-01	MOTOR	RP	1					
11	4275-1182-01	DAMPER ROLL		1					
12	4275-1055-01	GLASS		1					
13	4279-1033-01	ROLLER		1					
14	4275-1166-01	GUIDE ASSY		1					
INDEX	DADTNO	DADT NAME	REC	OTV					
							SEIY		
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		
INDEX	PART NO.	PART NAME	REC	QIY			SFIX		
INDEX	PART NO.	PART NAME	HEC	QIY			SFIX		
INDEX	PAHT NO.	PART NAME	HEC	QIY			SFIX		
INDEX	PART NU.	PART NAME	REC	QIY			SFIX		
INDEX	PART NU.	PART NAME	REC	QIY			SFIX		
INDEX	PART NU.	PART NAME	REC	QIY			SFIX		
INDEX	PART NU.	PARI NAME	REC	QIY			SFIX		
INDEX	PART NU.	PARI NAME	REC	QIY			SFIX		
INDEA	PART NU.	PART NAME	REC	QIY			SFIX		
INDEA	PART NU.	PART NAME	REC	QIY			SFIX		
INDEA	PART NU.	PART NAME	REC	QIY			SFIX		
INDEA	PART NU.	PARI NAME	REC	QIY			SFIX		
INDEA	PART NU.	PART NAME	REC	QIY			SFIX		
INDEA	PART NU.	PART NAME	HEC	QIY			SFIX		
INDEA	PART NU.	PART NAME	HEC	QIY.			SFIX		
INDEA	PART NU.	PART NAME	REC	QIY.			SFIX		
INDEA	PART NU.	PART NAME	REC	QIY.			SFIX		

10 SCANNER SECTION PARTS MANUAL




INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4283-1003-01	UNIT PARTS	RP	1					
02	4283-1021-01	PWB		1					
03	4283-1020-01	LAMP	RP	1					
04	4275-1027-01	MIRROR		1					
05	4275-1036-01	MIRROR		1					
06	4275-1035-01	MIRROR		1					
07	4275-1010-01	PWB-INVERTER	RP	1					
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		
	I								




INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4283-1067-01	COVER		1	19	4275-1107-01	SHEET		1
02	4256-1081-01	WASHER		2	20	4283-1030-01	SPONGE		1
03	4275-1157-01	SPEAKER	RP	1	21	4283-1035-01	LABEL		1
04	4283-1066-01	COVER		1	22	4283-1029-01	SHEET		1
05	4283-1064-01	GUIDE		1	23	4283-1030-01	SPONGE		1
06	4283-1065-01	GUIDE		1	24	4283-1068-01	COVER		1
07	4275-1143-01	PWB-CONNECT		1					
80	4283-1032-01	SHEET		1					
09	4275-1042-01	GROUND PLATE		1					
10	4275-1179-01	CORD CLAMP		1					
11	4275-1178-01	SPACER		2					
12	4283-1004-01	PWB	RP	1					
13	4275-1011-01	PWB-NCU	RP	1					
14	4242-1046-01	COVER		1					
15	4278-1479-01	COVER		1					
16	4275-1012-01	PWB-MODULAR	RP	1					
17	4275-1041-01	COVER		1					
18	4275-1024-01	PWB-PRINTER I/F	RP	1					
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		

12 CASSETTE PARTS MANUAL



INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4283-1071-01	RIGHT COVER		1	19	4275-1174-01	ROLL ASSY		2
02	4275-1026-01	FOOT		4	20	4278-1088-01	ROLL		2
03	4275-1175-01	BUSHING		4	21	4283-1072-01	LEFT COVER		1
04	4275-1017-01	TAKE-UP ROLLER	RP	2	22	4275-1130-01	PLATE SPRING		2
05	4275-1116-01	SHEET		2	23	4275-1131-01	HOLDER		2
06	4283-1042-01	SPONGE		2	24	4275-1138-01	LEVER		1
07	4275-1122-01	GEAR 13/45T		1	25	4283-1044-01	SPACER		2
08	4275-1123-01	GEAR 23T		2	26	4275-1137-01	INDICATOR		1
09	4275-1126-01	GEAR		1	27	4275-1140-01	SHEET		1
10	4275-1124-01	GEAR 41T		1	28	4283-1073-01	COVER		1
11	4275-1118-01	ROLLER		1	29	4275-1134-01	SPACER		2
12	4275-1125-01	GEAR		2	30	4275-1142-01	LABEL		1
13	4283-1041-01	PWB	RP	1	31	4283-1070-01	GUIDE ASSY		1
14	4275-1135-01	SPACER		2	32	4275-1133-01	SPACER		2
15	4254-1099-01	CABLE TIE		1	33	4275-1172-01	LIFTING PLATE		1
16	4275-1019-01	PWB-SWITCH	RP	1	34	4283-1069-01	CASSETTE ASSY		1
17	4275-1018-01	ACTUATOR		1					
18	4275-1021-01	SOLENOID	RP	1					
INDEX	PART NO.	PART NAME	REC	QTY			SFIX		

13 HANDSET/ACCESSORIES PARTS MANUAL



INDEX	PART NO.	PART NAME	REC	QTY	INDEX	PART NO.	PART NAME	REC	QTY
01	4283-1046-02	COUNTER		1					
02	4253-1138-01	HOLDER		1					
03	4283-1079-01	HANDSET		1					
04	4271-1014-01	SPIRAL CORD		1					
05	4256-1127-01	MODULAR CORD		1					
06	4275-1186-01	POWER CORD		1					
07	4283-1049-01	LABEL		1					
08	4283-1048-01	SHEET		1					
09	4283-1076-01	TRAY		1					
10	4282-1080-01	STAMP		1					
11	4283-1080-01	MEMORY 2MB		1					
12	4283-1081-01	MEMORY 4MB		1					
13	4283-1082-01	MEMORY 8MB		1					
14	4278-1496-01	JIG		1					
15	4278-1497-01	HARNESS		1					
16	4278-1498-01	HARNESS		1					
17	4283-1045-01	UNIT PARTS		1					
				0=1			2-11		1
INDEX	PART NO.	PART NAME	REC	QIY			SFIX		
1									

27

## 14 SCREWS AND WASHERS PARTS MANUAL

INDEX	PART NO.	PART NAME	ILLUST	INDEX	PART NO.	PART NAME	ILLUST	INDEX	PART NO.	PART NAME	ILLUST
1305 1308	9646-0306-13 9646-0308-13	SCREW									
2514	9642-0406-21	SCREW									
3405	9733-0310-13	TAPPING SCREW									
3501 3504 3519	9735-0306-13 9735-0308-13 9735-0312-13	TAPPING SCREW									
3704 3705	9739-0308-13 9739-0306-13	TAPPING SCREW	φ <sub>10</sub> φ								
3907	9742-0308-13	TAPPING SCREW									
4307	9770-0308-13	TAPPING SCREW									
8302	9712-0400-13	WASHER	<b>(i)</b> }								
9107	9721-0400-01	RETAINING RING	S								

### 15 NUMERICAL INDEX PARTS MANUAL

0956-2015-01   03   06
0992-3720-01 04 05 1 4275-1062-01 07 17 1 4283-1004-01 11 12 1 0992-4015-03 05 23 1 4275-1066-01 07 05 2 4283-1005-01 06 08 1 0992-4101-12 02 19 1 4275-1068-01 07 04 1 4283-1006-01 06 04 1 0992-4201-01 04 11 1 4275-1070-01 09 05 1 4283-1007-01 06 13 1 0992-4203-01 04 10 1 4275-1071-01 07 03 2 4283-1007-01 06 13 1 0992-4204-12 04 13 1 4275-1072-01 09 07 1 4283-1011-01 06 25 1 0992-4206-12 04 09 1 4275-1073-01 09 08 1 4283-1011-01 06 12 4 0992-4206-01 04 07 1 4275-1073-01 09 08 1 4283-1011-01 06 12 4 0992-4206-01 04 08 1 4275-1075-01 07 11 1 1 4283-1014-01 06 02 8 0992-4210-01 04 08 1 4275-1075-01 07 11 1 1 4283-1014-01 06 02 8 0992-4210-01 04 08 1 4275-1075-01 07 11 1 1 4283-1015-01 06 11 1 0992-5512-01 05 07 1 4275-1078-01 07 12 1 4283-1015-01 06 32 1 0992-5512-01 05 07 1 4275-1078-01 07 12 1 4283-1016-01 06 32 1 0992-5512-10 05 08 2 4275-1111-01 06 41 1 4283-1017-01 06 33 1 00992-5512-10 05 08 2 4275-1111-01 06 41 1 4283-1018-01 07 15 1 0992-5553-03 05 11 3 4275-1116-01 12 11 1 1 4283-1018-01 07 15 1 0992-5553-03 05 11 3 4275-1116-01 12 11 1 1 1 4283-1010-01 10 03 1



Copyright 1999 MINOLTA Co., Ltd. Printed in Japan